



# Penn Reel Parts list for Model: 130 International

KEY PART		DESCRIPTION	KEY PART		DESCRIPTION
NO	NO.		NO	NO.	
1	1-130	R.S. PLATE ASSEMBLY	40	55-130	LEFT SIDE BEARING
2	2-130	QUADRANT RING	41	41-130	L.S. BEARING SPRING
3	3-130	BRIDGE (INNER)	51	51-130	HANDLE KNOB
3A	3A-130	BRIDGE (OUTER)	54	54-130	HARNES LUG (2 REQ.)
3B	55-130	BRIDGE BEARING (OUTER)	54A	54A-130	ROD BRACE LUG (2 REQ.)
3C	55-130	BRIDGE BEARING (INNER)	55	55-130	SPOOL BEARING (2 REQ.)
4	4-130	CAM THRUST WASHER	56	56C-117	ROD BRACE
5	5-130	MAIN GEAR	59	59-130	SLOTTED WASHER
6	6-130	DRAG WASHER	60A	60A-130	BACKING WASHER
6A	6-155	LEATHER SPACING WASHER	62	62-50	CLICK SPRING
7A	7A-130	FLOATING DRAG WASHER	69	69-130	LOCATING PIN (2 REQ.)
13	13-130	PINION GEAR	69B	69B-130	RETAINING RING (2 REQ.)
14	49-710	DOG SPRING (3 REQ.)	81	81-130	RATCHET
15	15-130	DOG (3 REQ.)	91	91-130	HANDLE SHAFT
16	16-130	BRIDGE MTG. SCREW (OUTER) (3 REQ.)	95	95-130	CLICK TONGUE BUSHING *
16H	16H-130	BRIDGE MTG. SCREW (INNER)	95B	38-710	CLICK BUSHING NUT *
18	18-130	CLUTCH SPRINGS (2 REQ.)	101	118-80S	DRIVE PLATE SCREWS (8 REQ.)
18A	95A-20	CLICK BUSHING WASHER *	110	110-50	CENTER QUADRANT SCREWS (4 REQ.)
19	19-130	ECCENTRIC CAM	112	112-130	ECCENTRIC LEVER KNOB
21	21-130	ECCENTRIC LEVER	112A	112A-130	ECCENTRIC KNOB SCREW
22	50-704	DOG SCREWS (3 REQ.)	113	113-130	ECCENTRIC LEVER CAP
23	23-130	HANDLE NUT	117	117-130	DRIVE PLATE (OUTER)
24	24-130	HANDLE COMPLETE	117A	117A-130	DRIVE PLATE (INNER)
26	55-130	RIGHT SIDE BEARING	123	123-50	DRAG COVER SCREW
27	27-130	LEFT SIDE PLATE	124	124-130	BRIDGE COVER (OUTER)
29	29L-130	SPOOL	124A	124A-130	BRIDGE COVER (INNER)
30	30-130	STAND	134A	134A-130	HANDLE SPACING COLLAR
30A	30A-130	DOWEL TUBE (6 REQ.)	134B	134B-130	BEARING SPACING BUSHING
31A	31-130	STAND SCREWS (6 REQ.)	138	101-30	RATCHET SCREWS (4 REQ.)
31	16H-130	QUADRANT SCREW	140	140-115	FELT WASHER
33R	33R-130	RINGED ROD CLAMP	141	141-130	CAM FOLLOWER
34	34-116	ROD CLAMP SCREW W/NUTS	142	142-130	CAM FOLLOWER PIN (2 REQ.)
35	35-130	CLICK TONGUE	143	143-130	ADJUSTING SCREW
36	36-50	CLICK BUTTON	144	144-130	PRESET KNOB
36A	36-700	CLICK BUTTON NUT *	144C	144C-130	PRESET PINION
37	37-130	FRAME POST	144D	144D-130	PRESET GEAR
37A	37A-130	SPACER BAR	156	156-130	DRAG COVER
38	38-130	POST SCREW (11 REQ.)	157	157-130	QUADRANT SPACER BUSHING (2 REQ.)
39	39-130	SPECIAL POST SCREW (1)	161	161-130	STOP PIN BUSHING (2 REQ.)
			162	162-130	STOP PIN SPRING (2 REQ.)

\* NOT SHOWN

NOTE: Many of www.pennparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept.  
SBT Ver. 032115

\*154 154-130 Shim, Spool Shaft

\*50 50-704 screws to hold cam housing into handle side plate, not officially assigned a number by Penn, but they say use the 50-704 when replacing