




# PARTS LIST FOR INTERNATIONAL 130H



www.PENNparts.com  
**Scott's Bait & Tackle**  
Penn Parts Dept.  
945 Radio Road  
Tuckerton NJ 08087  
(609) 296-1300  
No Minimum Order!  
Plus, Parts in stock  
that Penn doesn't  
carry anymore.

SBT Ver 032115

Penn Reel Parts list for Model: 130H INTERNATIONAL

**KEY PART**

<b>NO</b>	<b>NO.</b>	<b>DESCRIPTION</b>
1	1-130	R.S. PLATE ASSEMBLY
2	2-130	QUADRANT RING
3	3-130	BRIDGE (INNER)
3A	3A-130	BRIDGE (OUTER)
3B	55-130	BRIDGE BEARING (OUTER)
3C	55-130	BRIDGE BEARING (INNER)
4	4-130	CAM THRUST WASHER
5	5-130H	MAIN GEAR
6	6-130	DRAG WASHER
6A	6-155	LEATHER SPACING WASHER
7A	7A-130	FLOATING DRAG WASHER
13	13-130H	PINION GEAR
14	49-710	DOG SPRING (3 REQ.)
15	15-130	DOG (3 REQ.)
16	16-130	BRIDGE MTG. SCREW (OUTER) (3 REQ.)
16H	16H-130	BRIDGE MTG. SCREW (INNER)
18	18-130	CLUTCH SPRINGS (2 REQ.)
18A	95A-20	CLICK BUSHING WASHER *
19	19-130	ECCENTRIC CAM
21	21-130	ECCENTRIC LEVER
22	50-704	DOG SCREWS (3 REQ.)
23	23-130	HANDLE NUT
24	24-130	HANDLE COMPLETE
26	55-130	RIGHT SIDE BEARING
27	27-130	LEFT SIDE PLATE
29	29L-130	SPOOL
30	30-130	STAND
30A	30A-130	DOWEL TUBE (6 REQ.)
31A	31-130	STAND SCREWS (6 REQ.)
31	16H-130	QUADRANT SCREW
33R	33R-130	RINGED ROD CLAMP
34	34-116	ROD CLAMP SCREW W/NUTS
35	35-130	CLICK TONGUE
36	36-50	CLICK BUTTON
36A	36-700	CLICK BUTTON NUT *
37	37-130	FRAME POST
37A	37A-130H	SPACER BAR
38	38-130	POST SCREW (11 REQ.)
39	39-130	SPECIAL POST SCREW (1)

**KEY PART**

<b>NO</b>	<b>NO.</b>	<b>DESCRIPTION</b>
40	55-130	LEFT SIDE BEARING
41	41-130	L.S. BEARING SPRING
51	51-130	HANDLE KNOB
54	54-130	HARNES LUG (2 REQ.)
54A	54A-130	ROD BRACE LUG (2 REQ.)
55	55-130	SPOOL BEARING (2 REQ.)
56	56C-117	ROD BRACE
59	59-130	SLOTTED WASHER
60A	60A-130	BACKING WASHER
62	62-50	CLICK SPRING
69	69-130	LOCATING PIN (2 REQ.)
69B	69B-130	RETAINING RING (2 REQ.)
81	81-130	RATCHET
91	91-130	HANDLE SHAFT
95	95-130	CLICK TONGUE BUSHING *
95B	38-710	CLICK BUSHING NUT *
101	118-80S	DRIVE PLATE SCREWS (8 REQ.)
110	110-50	CENTER QUADRANT SCREWS (4 REQ.)
112	112-130	ECCENTRIC LEVER KNOB
112A	112A-130	ECCENTRIC KNOB SCREW
113	113-130	ECCENTRIC LEVER CAP
117	117-130	DRIVE PLATE (OUTER)
117A	117A-130	DRIVE PLATE (INNER)
123	123-50	DRAG COVER SCREW
124	124-130	BRIDGE COVER (OUTER)
124A	124A-130	BRIDGE COVER (INNER)
134A	134A-130	HANDLE SPACING COLLAR
134B	134B-130	BEARING SPACING BUSHING
138	101-30	RATCHET SCREWS (4 REQ.)
140	140-115	FELT WASHER
141	141-130	CAM FOLLOWER
142	142-130	CAM FOLLOWER PIN (2 REQ.)
143	143-130	ADJUSTING SCREW
144	144-130	PRESET KNOB
144C	144C-130	PRESET PINION
144D	144D-130	PRESET GEAR
156	156-130	DRAG COVER
157	157-130	QUADRANT SPACER BUSHING (2 REQ.)
161	161-130	STOP PIN BUSHING (2 REQ.)
162	162-130	STOP PIN SPRING (2 REQ.)

\* NOT SHOWN

NOTE: Many of www.pennparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept.  
SBT Ver. 032115

\*154 154-130 Shim, Spool Shaft

\*50 50-704 screws to hold cam housing into handle side plate, not officially assigned a number by Penn, but they say use the 50-704 when replacing