



**PARTS LIST FOR INTERNATIONAL 50**

[www.PENNparts.com](http://www.PENNparts.com)

**Scott's Bait & Tackle**

Penn Parts Dept.  
 945 Radio Road  
 Tuckerton NJ 08087  
 (609) 296-1300

No Minimum Order!  
 Plus, Parts in stock  
 that Penn doesn't  
 carry anymore.

**SBT Ver 100816**

## Penn Reel Parts list for Model: 50 International

KEY NO	PART NO.	DESCRIPTION	KEY NO	PART NO.	DESCRIPTION
1	1-50	RIGHT SIDE PLATE ASSEMBLY (can sub 1-50TN see notes below)	37	37-50	FRAME POST
2	2-50	QUADRANT RING	37A	37A-50	SPACER BAR
3	3-50	BRIDGE ASSEMBLY	38	38-50	POST SCREW
4	4-50	CAM THRUST WASHER	39	39-12	BRIDGE SCREW
5	5-50	MAIN GEAR	39-50	39-50	SPECIAL POST SCREW
6A	6-155	SPACER WASHER	40	55-80	LEFT SIDE BEARING
7A	7-50	SPOOL-METAL WASHER (old 7A-50)	41	41-50S	L.S. BEARING SPRING
9	9-50	SPACING SLEEVE (NOT SHOWN)	54	54-50	HARNES LUG
13	13-50	PINION GEAR	55	55-50	BALL BEARING (2 REQ.)
14	14-50	DOG SPRING (2 REQ.)	59	59-50	SLOTTED WASHER
15	15-50	DOG (2 REQ.)	60	60-50	BACKING WASHER
18	18-50	DISC CLUTCH SPRING	69	69-50	LOCATING PIN
18A	95A-20	CLICK BUSHING WASHER (N/S)	69B	69B-50	RETAINING PIN
19	19-50W	ECCENTRIC CAM	81	81-50	RATCHET
21	21-50	ECCENTRIC LEVER	101	101-30	DRAG WASHER SCREW (4 REQ.)
22	22-109	DOG SPRING SCREW	110	110-50	HANDLE LOCK SCREW
23	23-114	HANDLE SCREW	110A	110A-50	HANDLE LOCKING PLATE
24	24-50T	HANDLE COMPLETE	112	112-50	ECCENTRIC LEVER KNOB
26	55-50	RIGHT SIDE BEARING	112A	112A-50	ECCENTRIC KNOB SCREW
27	27-50	L.S. PLATE ASSEMBLY	113	113-50	ECCENTRIC LEVER CAP
29	29L-50T	SPOOL	117D	117DN-50	DRIVE PLATE ASSEMBLY
30	30-50	STAND	118	38-7	MAIN GEAR PLATE SCREW
31	31-50	STAND SCREW	119	119-50	MAIN GEAR PLATE
31-20	31-20	QUADRANT SCREW	123	123-50	DRAG COVER SCREWS (4 Req.)
32	32-14	CENTER QUADRANT SCREW	124	124-50	BRIDGE COVER
33	33-114	ROD CLAMP MODEL	134	134-50	GEAR STUD
33R	33R-114	RINGED ROD CLAMP (OPTIONAL)	134A	134A-50	GEAR STUD WASHER
34	34-49	CLAMP STUD (2 REQ.)	138	101-30	RATCHET SCREW

141	141-50	CAM FOLLOWER	152A	152A-40	ROD CLAMP ACORN NUT (2 REQ.)
142	142-50	CAM FOLLOWER PIN (2 REQ.)	156	156-50	DRAG COVER
143	143-50	ADJUSTING SCREW	157	157-50	QUADRANT SPACER BUSHING (2 REQ.)
144	144-50	PRESET KNOB	161	161-50	LOCATING PIN BUSHING
149	149-200	ROD CLAMP HEX NUT (2 REQ.)	162	162-50	LOCATING PIN SPRING

NOTE: Many of www.pennparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept.  
SBT Version 100816

\*154 154-50 Shim, Spool Shaft

**\*NOT SHOWN**

6	6-50	DRAG WASHER	NOTES: 1-50 sideplate discontinued but can be subbed with 1-50TN sideplate. There are two extra screw holes on the TN plate for posts...possible to epoxy screw pieces in the extra holes just to cosmetically cover them.
117	117-50	DRIVE PLATE	
163	101-30	DRIVE PLATE SCREW	
<b>These parts discontinued replaced by the 117DN-50 Drive Plate Assembly</b>			

<u>OLDER DESIGN</u>			<u>NEWER DESIGN</u>		
35	35-50	CLICK TONGUE (Old# 35/1-50)	35	35-50N	CLICK TONGUE
36	36-50	CLICK BUTTON (Old# 36/1-50)	36	36N-50	CLICK BUTTON
36A	36-700	CLICK BUTTON NUT	36A	36-700	CLICK BUTTON NUT
		N/A	36S	36S-80ST	CLICK BUTTON CAP
38A	38-710	CLICK BUSHING NUT	38A	38-710	CLICK BUSHING NUT
62	62-50	CLICK SPRING	62	62-50	CLICK SPRING
95	95-50	CLICK TONGUE BUSHING	95	95-50	CLICK TONGUE BUSHING
		N/A	95A	95A-20	CLICK BUSHING WASHER
		N/A	95C	95A-50	CLICK BUSHING WASHER
		N/A	**	36C-50	CLICK BUTTON COMPLETE ASSEMBLY **

**NOTES:** The 36C-50 click button assembly can be used on the older plates  
There are photos of the plates and clicker parts in the www.pennparts.com website for comparison  
Diameter changed on button and tongue