





# PENN International 80TW



[www.PENNparts.com](http://www.PENNparts.com)



**Penn Parts Dept.**  
945 Radio Road  
Tuckerton NJ 08087  
(609) 296-1300  
**No Minimum Order!**  
Plus, Parts in stock  
that Penn doesn't  
carry anymore.

## Penn Reel Parts list for:

Model: 80TW

KEY NO	PART NO.	DESCRIPTION	KEY NO	PART NO.	DESCRIPTION
1	1N-80T	RIGHT SIDE PLATE ASSEMBLY	69	69-50	LOCATING PIN (2 REQ.)
2	2-80	QUADRANT RING	69B	69B-50	RETAINING RING (3 REQ.)
3	3-80	BRIDGE	81	81-80S	RATCHET
4	4-50	CAM THRUST WASHER (OLD #4-80)	95A	95A-20	CLICK BUSHING WASHER
5	5-80	MAIN GEAR	95B	38-710	CLICK BUSHING NUT
6A	6-155	SPACER WASHER	95C	95C-80ST	CLICK ADJUSTMENT RING
7	7A-80	METAL DRAG WASHER	95N	95N-80ST	CLICK TONGUE BUSHING
9	9-80	SLEEVE SPACER	95R	95R-80ST	CLICK O-RING
13	13-80W	PINION GEAR	95S	95S-80ST	CLICK SPRING SLIDER
14	14-50	DOG SPRING (2 REQ.)	95W	95W-80ST	EARRED SPRING WASHER
15	15-50	DOG (2 REQ.)	99	99-116	HARNESS SCREW HOOK (UPPER) (2REQ.)
18	18-80W	DISC CLUTCH SPRING (4 REQ.)	101	101-30	RATCHET SCREW (6 REQ.)
19	19H-80	ECCENTRIC CAM	110	110-50	HANDLE LOCK SCREW
21	21-80	ECCENTRIC LEVER	110A	110A-50	HANDLE LOCKING PLATE
22	22-109	DOG SPRING SCREWS (2 REQ.)	110T	110T-50	QUADRANT SCREW (2 REQ.)
23	23-80T	HANDLE SCREW	112	112-50	ECCENTRIC LEVER KNOB
24	24-80ST	HANDLE COMPLETE	112A	112A-50	ECCENTRIC KNOB SCREW
27	27-80T	L.S. PLATE ASSEMBLY	113	113-50	ECCENTRIC LEVER CAP
29L	29L-80SW	SPOOL	117	117DN-80T	DRIVE PLATE (OUTER)
30	30-80S	STAND	117A	117AN-80T	DRIVE PLATE (INNER)
31	31T-20	SHORT QUADRANT SCREW	118	118-80	COUPLING PLATE SCREW (3 REQ.)
33R	33-130ST	ROD CLAMP	119	119-80	COUPLING PLATE
34	34-80T	CLAMP SCREW (2 REQ.)	123	123-50	DRAG COVER SCREW (4REQ.)
34C	34C-80T	ROD CLAMP SCREW W/NUT	124	124-80	BRIDGE COVER
35	35-80ST	CLICK TONGUE	*	125-80	CAM HOUSING
36	36-80ST	CLICK BUTTON	134N	134N-80	GEAR STUD
36A	36-700	CLICK BUTTON NUT	134A	134A-80	GEAR STUD WASHER
36S	36S-80STW	CLICK BUTTON CAP	141	141-80	CAM FOLLOWER
38	38T-50	FRAME SCREW	142	142-80ST	CAM FOLLOWER PINS (2 REQ.)
39	39-12	BRIDGE COVER SCREWS (3 REQ.)	143	143-80	ADJUSTING SCREW
39A	39-50	LONG QUADRANT SCREW	144	144-50	PRESET KNOB
41	41-50	L.S. BEARING SPRING	152A	152A-80T	ROD CLAMP ACORN NUT
54A	54A-80S	TOP HARNESS LUG (2 REQ.)	155	155-116	TURNBUCKLE (2 REQ.)
54B	54B-80S	BOTTOM HARNESS LUG (2 REQ.)	156	156-80	DRAG COVER
55	55-80	BALL BEARING (4 REQ.)	157	157-50	QUADRANT SPACER BUSHING (2 REQ.)
56	56-116	ROD BRACE	161	161-50	LOCATING PIN BUSHING (2 REQ.)
56C	56C-80ST	ROD BRACE ASSEMBLY (COMPLETE)	162	162-50	LOCATING PIN SPRING (2 REQ.)
59	59-50	SLOTTED WASHER	165	165-116	HARNESS SCREW HOOK (LOWER) (2 REQ.)
60	60-50	BACKING WASHER	183	183-80TW	TUBE FRAME
62	62-50	CLICK SPRING	264	264-80T	STAND GASKET
63	63-30T	STAND SCREWS (4 REQ.)			*NOT SHOWN

NOTE: Many of www.pennparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept.  
SBT Ver. 122910

\*154

154-80 Shim, Spool Shaft