



## Penn Reel Parts list for Model: TRQ100LD International Torque Leverdrag

KEY NO	PART NO.	DESCRIPTION	KEY NO	PART NO.	DESCRIPTION
1	1-100LD	RIGHT SIDE PLATE	44	44-300T	SCREW ( USES 2 )
1D	1D-100T	BACKING PLATE	50	50-25	GEAR STUD SHIELD
2	2-100LD	DRAG LEVER QUADRANT	62	62-300LD	CLICK SPRING
2A	2A-100LD	DRAG LEVER RATCHET	69	69-12VS	LOCATING PIN ( USES 2 )
4	4-12LT	DRAG LEVER THRUST WASHER	69C	69C-15KG	RETAINING RING
4A	4-300LD	CAM THRUST WASHER	81	81-100LD	CLICK RACHET PLATE
5	5-100LD	MAIN GEAR	86	86-100LD	KEYED METAL DRAG WASHER ( USES 2 )
6	6-100LD	DRAG WASHER ( USES 3 )	86A	86A-100LD	DRAG BUSHING ASSEMBLY
6B	6B-100LD	DRAG ENGAGEMENT WASHER	95	95-100LD	CLICK BUSHING
13	13-100LD	PINION	95A	95A-20	CLICK BUSHING WASHER
14	14-100LD	DOG SPRING ( USES 2 )	95AB	95A-50	CLICK LOCKING PLATE
15	15-100LD	DOG, ANTI-REVERSE ( USES 2 )	101	101-30	MOUNTING SCREW ( USES 2 )
18L	18L-300LD	CLUTCH SPRING LIGHT ( USES 4 )	101A	101-50S	MOUNTING SCREW ( USES 8 )
19	19-300LD	CAM	101B	101-80ST	STAND SCREW ( USES 4 )
20	20-722	LEFT SIDE BALL BEARING	110A	110A-555	HANDLE NUT CAP
20A	20-4200	SPOOL BALL BEARING ( USES 2 )	112	112-100LD	LEVER KNOB SCREW
21	21-100LD	DRAG LEVER	112A	112A-100LD	LEVER KNOB SLEEVE
23	23-300LD	HANDLE SCREW	112B	112B-100LD	LEVER KNOB
24	24-200LD	HANDLE	112BA	112B-70	LEVER KNOB SCREW
26N	26N-25	RIGHT SIDE BALL BEARING	112C	112C-30VS	CLICK PLATE
27	27-100LD	LEFT SIDE PLATE	112E	112E-100LD	LEVER CLICK HOUSING
29	29L-100LD	SPOOL	117	117-100LD	DRAG HOUSING
30	30-16VS	STAND	119	119-50	COUPLING PLATE
31T	31T-70	SCREW ( USES 2 )	124L	124L-100LD	BRIDGE COVER ASSEMBLY
32	32-15	HANDLE CAP SCREW	128A	128A-100LD	DRIVER
32A	32-100LD	QUADRANT SCREW ( USES 2 )	128B	128B-100LD	DRIVE PLATE
33	33N-113	ROD CLAMP	128C	128C-100LD	DRIVER RETAINER
34	34-16VS	ROD CLAMP SCREW ( USES 2 )	134	134-200LD2S	GEAR STUD (rep. orig. #134-200LD)
35	35-100LD	CLICK TONGUE	141	141-300LD	CAM FOLLOWER
36	36-700	CLICK BUTTON NUT	143	143-300LD	ADJUSTING SCREW
36N	36N-50	CLICK BUTTON	149	149-45	ROD CLAMP NUT ( USES 2 )
36S	36S-80ST	CLICK BUTTON CAP	149A	149-200	ROD CLAMP HEX NUT ( USES 2 )
38	38-710	CLICK BUSHING NUT	154	154-100LD	SPOOL SHIM (2 - OPTIONAL IF NEEDED)
38N	38N-7	COUPLING PLATE SCREW ( USES 3 )	156	156-100LD	DRAG HOUSING COVER
39	39-300LD	LEFT SIDE SCREW ( USES 6 )	162	162-100LD	SCREW (2 REQUIRED)
39S	39S-965	DRAG COVER SCREW ( USES 4 )	183	183-100LD	FRAME
41	41-100LD	DIVE CLUTCH SPRING	183	183-100LDE	FRAME (FOR EUROPEAN MODELS)
41A	41A-100LD	DRAG DISENGAGEMENT SPRING	302D	302D-525MAG	LEVER DRAG SPRING

NOTE: Many of [www.pennparts.com](http://www.pennparts.com) schematics include changes that were either made by Penn, or errors found and corrected by our parts dept.

SBT VER. 11/27/09 (BASED ON PENNS 407-100LD Rev 3)